
INSTRUCTION




10X20FT-BOOTH-G

INSTRUCTION 10X20FT-BOOTH-G

STEPS

(1) Hardware





(2) Printed Graphic Fabric Banner (Optional)




STEP 01

Connect to make long poles according to labelings.










STEP 02

Connect long poles with corner poles according to labelings.








STEPS

STEP 03

Slide fabric banner on frame from top and zip up at bottom.









Same Steps for the rest back walls


Booth Set Assembly





STEP 01


Insert display stands onto feet by pressing their knobs.



STEPS


STEP 02

Interconnect display stands with C-shaped clips.



STEP 03


Screw TV mount with hex wrench.




STEPS

STEP 04

Screw light clips at top of display stands, slide lights onto them and adjust their direction.





10X20FT-BOOTH-G

INSTRUCTION Smart Reception Counter

STEPS

(1) Durable Plastic Hard Case, Aluminum Support Poles




(2) Printed Graphic Fabric Banner




STEP 01

Put hard case's top into fabric banner.



STEP 02

Insert support poles into hard case's top & bottom.




INSTRUCTION Smart Reception Counter

STEPS

STEP 04

Wrap fabric banner from bottom to top & twist it to be smooth, lay hard case's intermediate panel on podium's top.





INSTRUCTION Top Banner Stand

★ One Tool (Hex Wrench)

STEPS

(1) Aluminum pole




(2) MDF panel



(3) Fabric banner




(4) Optional Accessory



STEP 01

To assemble the poles according to labelling







INSTRUCTION Top Banner Stand

STEPS

STEP 02


To put the bottom MDF panel upside down and clip the fabric banner to the slot
To put the middle of fabric bottom into the middle of bottom panel slot and start the assembly



BOTTOM




PRESS



STEP 03

Insert the center pole into the base.








INSTRUCTION Top Banner Stand

STEPS

STEP 04

Stretch the cloth cover upward and put it into the top bracket. Pull the zipper on both sides to the middle to expose the hole of the LED light on the top of the bracket







Zip up fabric graphic




STEP 05

Slide the shelves through the open slits in the graphic and connect them to their support sockets.









INSTRUCTION Top Banner Stand

STEPS

STEP 06

Place the base of the light fitting in the hole in the middle of the profile.





DT-W-01 DT-W-02 DT-W-03


INSTRUCTION Display Counter

STEPS

(1) Straight Support Poles



(2) Top MDF Board
Bottom MDF Board





(3) Printed Graphic Fabric Banner



STEP 01

Insert fabric banner into bottom MDF board's slot and turn it over.









STEP 02

Screw straight support poles in top & bottom MDF boards' threaded holes and interconnect them in the middle.







INSTRUCTION Display Counter

STEP 03

Pull fabric banner from bottom to top and insert into top MDF board's slot.





PRESS





DT-C-03



DT-C-01



DT-C-02

INSTRUCTION Display Tower Counter


★ One Tool (Hex Wrench)

STEPS

(1) Straight Support Poles



(2) Top MDF Board, Bottom MDF Board, Acrylic Boards




(3) Printed Graphic Fabric Banner



STEP 01

Connect straight support poles by pressing knobs to lock.



STEP 02

Insert fabric banner into bottom MDF board's slot and turn it over.



BOTTOM



PRESS




STEPS

STEP 03

Screw straight support poles in bottom MDF board's threaded holes and place top MDF board on them.







STEP 04

Pull fabric banner from bottom to top and insert into top MDF board's slot.






PRESS




STEPS

STEP 05

Screw straight support poles with threaded holes filled onto nuts and place acrylic boards on them layer by layer.





INSTRUCTION

Display Tower Counter

STEPS



DT-S-02



DT-S-01



DT-S-03