
INSTRUCTION




10X20FT-BOOTH-14

INSTRUCTION 10X20FT-BOOTH-14

STEPS

(1) Hardware




(2) Printed Graphic Fabric Banner (Optional)



STEP 01

Connect to make long poles according to labelings.










STEP 02

Connect long poles with corner poles according to labelings, connect support pole onto frame.








INSTRUCTION 10X20FT-BOOTH-14

STEPS


STEP 03

Slide fabric banner on frame from top and zip up at bottom.




STEP 04

Insert display stand onto feet by pressing their knobs.



(1) Hardware



x4


(2) Printed Graphic Fabric Banner (Optional)




INSTRUCTION 10X20FT-BOOTH-14

STEPS


STEP 01 Connect to make long poles according to labelings.









STEP 02 Connect long poles with corner poles according to labelings.










STEP 03 Connect support poles onto frame.







STEP 04 Slide fabric banner on frame from top and zip up at bottom.








x2

INSTRUCTION 10X20FT-BOOTH-14

STEPS


(1) Hardware




(2) Printed Graphic Fabric Banner (Optional)



STEP 01 Connect to make long poles according to labelings.



STEP 02 Connect long poles with corner poles according to labelings.




INSTRUCTION 10X20FT-BOOTH-14

STEPS


STEP 03

Connect support poles onto column frame.



STEP 04

Slide fabric banner on frame from top and zip up at bottom.




x2

(1) Hardware




(2) Printed Graphic Fabric Banner (Optional)




INSTRUCTION 10X20FT-BOOTH-14

STEPS


STEP 01 Connect to make long poles according to labelings.




STEP 02 Connect long poles with corner poles according to labelings.



STEP 03 Connect support poles onto frame.




STEP 04 Slide fabric banner on frame from left and zip up at right.



STEPS

Booth Set Assembly






x2



x2


(5) TV Mount & Screw



x2



x8



A

(1) Base



x4

(2) 90° C-Shaped Clip



x4

(3) LED Light & Clip



x2




x2


(4) Arm Clip




x4

STEP 01 Connect support poles onto column frame and canopy.









x2

STEPS

STEP 02


Interconnect display stands with C-shaped clips.







STEP 03

Connect display stands with arm clips and Insert display stands onto feet by pressing their knobs.









STEPS

STEP 04 Screw TV mount with hex wrench.




STEP 05 Screw light clips at top of display stands, slide lights onto them and adjust their direction.



INSTRUCTION

10X20FT-BOOTH-14

STEPS



10X20FT-BOOTH-14

INSTRUCTION Smart Reception Counter

STEPS

(1) Durable Plastic Hard Case, Aluminum Support Poles




(2) Printed Graphic Fabric Banner




STEP 01

Put hard case's top into fabric banner.



STEP 02

Insert support poles into hard case's top & bottom.



INSTRUCTION Smart Reception Counter

STEPS

STEP 04

Wrap fabric banner from bottom to top & twist it to be smooth, lay hard case's intermediate panel on podium's top.

